

Creating a river table with epoxy resin can be an exciting and rewarding project. Here are the general steps involved in making a river table:

**1. Plan and design:** Determine the size, shape, and design of your river table. Consider the type of wood, the size and shape of the river or void, and any additional features or materials you want to incorporate into the table.

**2. Select the wood:** Choose a suitable piece of wood for the tabletop. Popular choices include live edge slabs or reclaimed wood with unique grain patterns. Prepare and sand the wood to achieve a smooth and level surface.

**3. Build a mold:** Construct a mold using a melamine board or other suitable material. The mold will hold the epoxy resin in place during the pouring and curing process. Make sure the mold is watertight and properly sealed to prevent any leakage.

**4. Seal the wood**: Apply a sealant or epoxy-compatible finish to the wood to prevent air bubbles and moisture from affecting the resin. This step helps create a clear and bubble-free resin pour.

**5.** Pour the base layer: Mix the epoxy resin according to the manufacturer's instructions. Pour a thin layer of resin into the mold to create a solid base. Use a heat gun or torch to remove any air bubbles that may have formed.

**6. Create the river effect:** Once the base layer has partially cured (reached a tacky stage but is not fully hardened), pour a coloured or tinted epoxy resin into the river void created in the mold. You can add pigments or dyes to achieve the desired colour effect. Use a stirring stick or brush to guide the resin and create the desired shape and movement.

**7. Embed additional elements (optional):** Consider adding decorative elements like rocks, shells, or dried flowers into the epoxy resin for added visual interest. Arrange them in the river void and make sure they are fully submerged and secured in place.

**8.** Pour the final layer: After the river effect has been created and any additional elements are in place, pour the remaining epoxy resin to fill the mold. Use a heat gun or torch to remove air bubbles and ensure a smooth surface.

**9. Curing and finishing:** Allow the epoxy resin to cure according to the manufacturer's instructions. This typically takes several days. Once fully cured, remove the table from the mold and sand the



surface to achieve a smooth finish. Apply a protective finish, such as varnish or polyurethane, to enhance the appearance and provide durability.

**10. Assemble the table:** Attach the table legs or other supports according to your design. Ensure they are securely fastened and able to support the weight of the tabletop.

Creating a river table requires careful attention to detail and patience. It's essential to follow the manufacturer's instructions for the epoxy resin and take appropriate safety precautions. Each project may have unique considerations, so adapt the steps as needed based on your specific design and materials.